

HSLIS e-Series™

Liquid Optical Particle Counter

Provides continuous, real-time monitoring of contamination levels in DI water and process chemicals.

Without measurement there is no control

The HSLIS e-Series (High Sensitivity Liquid In Situ) particle counter provides continuous, real-time monitoring of contamination levels in DI water and process chemicals. The combination of high sensitivity and low cost makes it ideal when large numbers of sensors and/or long term trending are required.

The HSLIS e-Series has sizing sensitivity down to 0.05 μm in DI water and 0.065 μm in process chemicals.

Integration of the HSLIS e-Series into Particle Measuring Systems' Facility Net software provides an economical way to monitor multiple flow systems and provide dedicated local display and control capabilities.



BENEFITS

- Monitor for long term trends in fluid quality
- Control and monitoring of multiple particle counters using Ethernet
- Low initial capital investment and lower maintenance cost with proven reliability of the HSLIS design
- Tabular and statistical process control (SPC) charts for detailed statistical information
- Alphanumeric paging and e-mailing functions to alert operator of data excursions
- Sensor status displays four-level alarm for monitoring out-of-spec condition
- Simplified data interpretation with real-time and retrieved time plots

FEATURES

- 4 channels
- 0.05, 0.1, 0.15, 0.2 μm size range
- Operates with an optimal flow rate of 100 ml/min \pm 10%
- Samples 0.25% of the flow volume or 0.25 ml/min
- Compatible with Facility Net software
- Existing network can be utilized with ethernet communication to Facility Net software

APPLICATIONS

- Real-time particle monitoring within chemical distribution systems
- Point-of-process monitoring
- Chemical packaging operations monitoring
- Chemical filter performance and efficiency characterization
- Performance testing of chemical handling components

HSLIS e-Series

Liquid Optical Particle Counter

Specifications

	M50e	M65e	M100e
Size range	0.05 – 0.2 µm	0.065 – 0.2 µm	0.1 – 1.0 µm
Channels	4		
Channel sizes	0.05, 0.1, 0.15, 0.2 µm	0.065, 0.1, 0.15, 0.2 µm	0.1, 0.2, 0.5, 1.0 µm
Flow rate	100 ml/min ± 10%	100 ml/min ± 10%	300 ml/min ± 10%
Sample volume	0.25 ml/min	0.6 ml/min	3.0 ml/min
Counting efficiency	100% of sample volume		
Maximum concentration	10,000 counts/ml		
Sample temperature	194 °F (90 °C)	212F (100°C)	212F (100°C)
Zero count	< 1000 counts/liter	< 2000 counts/liter	< 1000 counts/liter
Wetted surface materials	Delrin®, Kel-F®, Teflon®, Viton®, fused silica	Kalrez 4079, Kel-F, Teflon, sapphire	Kalrez 4079, Kel-F, Teflon, sapphire
Dimensions (L x W x H)	21 x 10.75 x 7 in (53 x 27 x 18 cm)		
Weight	28 lb (13 kg)		
Power	85 – 250 VAC, 50 – 60 Hz		
Calibration	Materials used are traceable to US National Institute of Standards and Technology (NIST) and/or Japanese Institute of Standards (JIS).		
Environment	Temperature: 50 – 95 °F (10 – 35 °C); Humidity: non-condensing		
Communications	Ethernet, 4-20 mA (5 outputs; 4 particle channels, 1 instrument status) RS-232 (set-up and diagnostics, no data)		

*Greater than 90% accuracy (less than 10% coincidence loss) at maximum recommended concentration.

HEADQUARTERS

5475 Airport Blvd
Boulder, Colorado 80301 USA
T: +1 303 443 7100

Instrument Service & Support
T: +1 800 557 6363

Customer Response Center
T: +1 877 475 3317
E: info@pmeasuring.com

www.pmeasuring.com
info@pmeasuring.com



GLOBAL OFFICES

AUSTRIA
T: +43 512 390 500
E: pmsaustria@pmeasuring.com

BENELUX
T: +32 10 23 71 56
E: pmsbelgium@pmeasuring.com

BRAZIL
T: +55 11 5188 8227
E: pmsbrazil@pmeasuring.com

CHINA
T: +86 21 6113 3600
E: pmschina@pmeasuring.com

FRANCE
T: 33(0)1 60 10 32 96
E: pmsfrance@pmeasuring.com

GERMANY
T: +49 6151 6671 632
E: pmsgermany@pmeasuring.com

ITALY
T: +39 06 9053 0130
E: pmsrl@pmeasuring.com

JAPAN
T: +81 44 589 3498
E: pmsjapan@pmeasuring.com

KOREA
T: +82 31 286 5790
E: pmskorea@pmeasuring.com

MEXICO
T: +52 55 2271 5106
E: pmsmexico@pmeasuring.com

NORDIC
T: +45 707 028 55
E: pmsnordic@pmeasuring.com

PUERTO RICO
T: +1 787 718 9096
E: pmspuertorico@pmeasuring.com

SINGAPORE
T: +65 6496 0330
E: pmsingapore@pmeasuring.com

SWITZERLAND
T: +41 71 987 01 01
E: pmsswitzerland@pmeasuring.com

TAIWAN
T: 886-3-5525300 Ext: 301
E: pms taiwan@pmeasuring.com



Teflon® is a registered trademark of The Chemours Company, FC, LLC. Delrin®, Kalrez® and Viton® are registered trademarks of DuPont. Kel-F® is a registered trademark of 3M. All other trademarks are the property of their respective owners. Particle Measuring Systems, Inc. reserves the right to change specifications without notice. © 2022 Particle Measuring Systems, Inc. All rights reserved.